

Configuring Microstation V8 XM for Power Office 2005 on XP

- Make sure that computer's files and folders are not hidden and the full path is displayed in the title bar. Change this by:

Left click on the *Windows Start* icon.

Left click on *Control Panel* then double left click on *Folder Options*. Left click on *View* tab and place a tick in the 'Display the full path in the title bar (Classic folders Only)' checkbox and then left click on '*Show hidden file and folders*' so that there is a dot in the radio button.

Left click on *Apply*

Left click *Ok* and close *Control Panel*.

- To configure Microstation V8 XM for PowerOffice. The User needs to define the path for the Cell library, Line Styles, Macros, Design Seed file and Toolbar File. This is explained below.

Cell Library

- Open Microstation and left click on *Workspace* left click on *Configuration*.
- In the *Configuration: User [Untitled]* window, search and select *MS_CellList* in the *View/Modify all configuration variables* window.
- Left click *Edit*.
- In the *Edit Configuration Variable* window, left click in the *Edit* select box and left click on *Prepend*.
- Right click on the *Windows Start* icon
- Left click on *Explore*.
- In the *Folders* window double left click on *Local Disk C:*.
- Double left click on the *Program Files* folder.
- Double click on the *Inspired Interfaces* folder.
- Double left click on the *PowerOffice* folder.
- Double left click on the *System Files* folder.
- In the address bar highlight the path. Right click and copy the path.
- Return to the Microstation *Edit Configuration Variable* Window, left click in the *New Value* block and right click and paste the path.
- Now type '**.cel* '.
- The path should read '*C:\Program Files \Inspired Interfaces \Power Office \System Files *.cel* '
- Select *OK*

Line Styles

- In the *Configuration: User [Untitled]* window, search and select *MS_Symbrsrc* in the *View/Modify all configuration variables* window.
- Left click *Edit*.
- In the *Edit Configuration Variable* window, left click in the *Edit Mode* select box
- Left click on *Prepend*.
- In *Configuration* Window, left click in the *New Value* block and right click to paste the path.
- Type '**.rsc* '
- The path should read '*C:\Program Files \InspiredInterfaces\ PowerOffice\ SystemFiles*.rsc* '
- Select *OK*

Macros

- In the *Configuration: User* window search and select *MS_Macro*.
- Left click on *edit*.
- In the *Edit Configuration Variable* window, left click in the *Edit Mode* select box and left click on *Prepend*.
- Open Windows *Explore*.
- In the Folders window double left click on *Local Disk C:*.
- Double left click on the *Program Files* folder.
- Double click on the *Inspired Interfaces* folder.
- Double left click on the *PowerOffice* folder.
- Left click on the *Macros V8XM* folder.
- In the address bar highlight the path. Right click and copy the path.
- Return to the Microstation *Edit Configuration Variable* Window, left click in the *New Value* block and right click and paste the path.
- Return to the Microstation Configuration Window, left click in the *New Value* block and paste.
- Type ' \ '
- The path should read ' C:\Program Files \Inspired Interfaces \PowerOffice \MacrosV8XM\ '
- Select *OK*

Design Seed File

- In *Workspace Configuration* search and select *MS_Designseed* and edit. In the *Edit Configuration Variable* window select *Overwrite*. Remove *design2d.dgn* and replace it with *Electrificationdesign.dgn*
- Left click *OK*
- Left click *OK* in the Configuration window.
- Select *YES* to save changes
- Open Windows *Explore*.
- In the Folders window double left click on *Local Disk C:*.
- Double left click on the *Program Files* folder.
- Double click on the *Inspired Interfaces* folder.
- Double left click on the *PowerOffice* folder.
- Left click on the *Support* file and select and copy the *ElectrificationDesign.dgn* file.
- Back in *Windows Explorer*, browse to [C:\Documents and Settings\All Users\Application Data\Bentley\Workspace\System\Seed](#) and paste *ElectrificationDesign.Dgn*

Toolbar File

- Right click on the *Windows Start* icon
- Left click on *Explore*.
- In the Folders window double left click on *Local Disk C:*.
- Double left click on the *Program Files* folder.
- Double left click on the *Inspired Interfaces* folder.
- Double left click on the *Power Office* folder.
- Double left click on the *System Files* folder.
- Left click on *Toolbar V8* folder.
- Right click on ' *ustn.m01* ' file.
- Left click copy.
- In your *Windows Explorer*, browse to *Local Disk C:\Documents and Settings\All Users\Application Data\Bentley\Workspace\Interfaces\Microstation\Default* folder.
- *Windows Explore* can now be closed.

- To view the Tool bar in Microstation select *Tools\Tool Boxes*. Scroll down to PO Electrification and tick all relevant boxes for PO Electrification
- Select *OK*