

## **Configuring Microstation V8 for Power Office 2005 on Windows XP**

- To configure Microstation V8 for PowerOffice. The User needs to define the path for the Cell library, Line Styles, Macros, Design Seed file and Toolbar File.
- Before starting make sure that computer's files and folders are not hidden and the full path is displayed in the title bar. Change this by:

In the Windows Control Panel, select Folder Options, View Tab select the radio button for "Show hidden files and folders" and apply.

### **Cell Library**

- Open Microstation\Workspace\Configuration.
- In the Configuration: User [untitled] window, search and select MS\_CellList in the View/Modify all configuration variables window.
- Select Edit.
- In the Edit Configuration Variable window, click Edit select box and select Prepend.
- Now in Windows Explore.
- Locate Local Disk C:\ Program Files\Inspired Interfaces\PowerOffice\SystemFiles.
- In the address bar highlight the path and copy the path.
- Return to the Microstation Edit Configuration Variable Window, click in the New Value block and paste the path.
- Now type \\*.cel.
- The path should read: C:\Program Files\Inspired Interfaces\PowerOffice\System Files\\*.cel
- Select OK

## Line Styles

- In the Configuration: User [Untitled] window, search and select MS\_Symbrsrc in the View/Modify all configuration variables window.
- Select Edit.
- In the Edit Configuration Variable window, click in the Edit Mode select box
- Select on Prepend.
- In Configuration Window, click in the New Value block and paste.
- Type \\*.rsc
- The path should read: C:\Program Files\Inspired Interfaces\PowerOffice\SystemFiles\\*.rsc
- Select OK

## Macros

- In the Configuration: User window search and select MS\_Macro.
- Select Edit.
- In the Edit Configuration Variable window, select Edit Mode and select Prepend.
- Back in Windows Explore\Local Disk C:\Program Files\Inspired Interfaces\PowerOffice\Macros V8
- In the address bar highlight the path and copy the path.
- Return to the Microstation Edit Configuration Variable Window, left click in the New Value block and paste the path.
- Type \
- The path should read: C:\Program Files\Inspired Interfaces\PowerOffice\MacrosV8\
- Select OK

## Design Seed File

- In Workspace Configuration search and select MS\_Designseed and edit. In the Edit Configuration Variable window select Overwrite. Remove design2d.dgn and replace it with ElectrificationDesign.dgn
  - Select OK
  - Select OK in the Configuration window.
  - Select YES to save changes
- 
- Open Windows Explore Local Disk C:\Program Files\Inspired Interfaces\PowerOffice\Support select and copy the ElectrificationDesign.dgn file.
  - In Windows Explorer Local Disk C:\Bentley\Workspace\System\Seed and paste ElectrificationDesign.Dgn

### **Toolbar File**

- In Windows\Explore\Local Disk C:\Program Files\Inspired Interfaces\PowerOffice\SystemFiles\Toolbar V8 select ustn.m01 and copy
  - Back in Windows\Explorer\Local Disk C:\Bentley\Workspace\Interfaces\Microstation\Default and paste the Ustn.m01 file
  - If Ustn.m01 already exists then call this file Ustn.m02
  - Windows Explore can now be closed.
- 
- To view the Tool bar in Microstation select Tools\Tool Boxes. Scroll down to PO Electrification and tick all relevant boxes for PO Electrification
  - Select OK